


AVVERTENZE:

- * LA SICUREZZA DELL'APPARECCHIO È GARANTITA SOLO CON L'USO APPROPRIATO DELLE SEGUENTI ISTRUZIONI, PERTANTO È NECESSARIO CONSERVARLE.
- * TOGLIERE LA TENSIONE PRIMA DI EFFETTUARE QUALSIASI TIPO DI MANUTENZIONE.
- * IL PRODOTTO VA INSTALLATO DA PERSONALE SPECIALIZZATO
- * LA BASE ED ALTRE PARTI DELL'APPARECCHIO NON DEVONO ESSERE RICOPERTE DAL TERRENO O VENIRE A CONTATTO CON SOSTANZE CHIMICHE AGGRESSIVE (DISERBANTI, FERTILIZZANTI, ECC.)
- * PULIRE PERIODICAMENTE LE PARTI RICOPERTE DA ACCUMULI DI TERRA.
- * UTILIZZARE CAVO DI ALIMENTAZIONE IN DOPPIA GUAINA, NON UTILIZZARE CAVI SINGOLI.
- * UTILIZZARE SOLO CAVI FLESSIBILI TIPO <HAR> O IDONEI PER UN UTILIZZO IN ESTERNO.
- * E' CONSIGLIABILE L'USO DI GRASSO AL SILICONE SUI FILETTI DELLE VITI DI CHIUSURA DELL'APPARECCHIO PER FACILITARNE LE MANUTENZIONI FUTURE.
- * NELLE VERSIONI CON LAMPADA 21W, LE DIMENSIONI MASSIME DELLA LAMPADA DEVONO ESSERE Ø80 L 160 MM
- * NELLE VERSIONI CON LAMPADA 30W, LE DIMENSIONI MASSIME DELLA LAMPADA DEVONO ESSERE Ø100 L 200 MM




ISTRUZIONI PER L'INSTALLAZIONE:

1. Smontare il cappello (1) svitando le viti (2) ed i tiranti (3), rimuovere lo schermo (4) per accedere al vano cablaggio.
2. Rimuovere il frangiluce(5); (solo per art.1056-1256).
3. Rimuovere il cono (7) e la piastra portacablaggio(6).
4. Introdurre il cavo all'interno della colonnina attraverso la base (8).
5. Fissare la colonna al suolo attraverso i tappi ad espansione (9) (non in dotazione)
6. Introdurre il cavo conduttore nel passafilo (10), fissarlo e collegare i conduttori alla morsettiera fissata alla piastra portacablaggio (6).
7. Rimontare la piastra portacablaggio attraverso le viti (11).
8. Montare il cono (7) serrando le viti (12).
9. Posizionare la scatola portacablaggio sulla colonnina facendo attenzione all'allineamento dei fori.
10. Montare la lampada (non in dotazione).
11. Riposizionare il frangiluce(5); (solo per art.1056-1256).
12. Avvitare il tirante (3), posizionare lo schermo (4) sulla scatola portacablaggio facendo attenzione al corretto posizionamento della guarnizione.
13. Posizionare il cappello (1) sulla parte superiore dello schermo (4) facendo attenzione al corretto posizionamento della guarnizione.
14. Completare il montaggio del cappello (1) avvitando le viti (2) sui tiranti (3).

Rev.1

WARNING:

- * SAFETY IS GUARANTEED ONLY IF THE FOLLOWING INSTRUCTIONS ARE PROPERLY APPLIED. THEREFORE IT IS MANDATORY TO PRESERVE THIS SHEET.
- * TURN OFF MAIN SUPPLY BEFORE TAKING ANY SERVICING.
- * THE PRODUCT SHOULD BE INSTALLED BY SPECIALIZED PERSONNEL
- * THE BASE AND THE OTHER PARTS OF THE PRODUCT CAN NOT BE COVERED BY SOIL OR PUT IN CONTACT WITH AGGRESSIVE CHEMICAL SUBSTANCES (HERBICIDES, FERTILIZINGS, ETC..).
- * CLEAN PERIODICALLY THE PARTS COVERED BY SOIL.
- * USE ONLY SUPPLY CABLES WITH DOUBLE SHEATH, DO NOT USE SINGLE CABLES.
- * USE ONLY FLEXIBLE CABLES (E.G. "HAR" TYPE), OR CABLES SUITABLE FOR OUTDOOR.
- * IT IS ADVISABLE TO USE THE SILICONE GREASE ON THE THREADED PARTS OF THE CLOSING SCREWS, IN ORDER TO MAKE THE FURTHER MAINTENANCE EASIER.
- * THE VERSIONS PRE-SET FOR LAMP 27W CAN BE EQUIPPED WITH LAMPS OF MAX. DIMENSION Ø80 L 160 MM .
- * THE VERSIONS PRE-SET FOR LAMP 30W CAN BE EQUIPPED WITH LAMP OF MAX. DIMENSION Ø100 L 200 MM.



INSTALLATION INSTRUCTIONS:

1. Disassemble the top (1) loosening screws (2) and connecting-rods (3), remove the diffuser(4).
2. Remove the antiglare baffle (5);(only for art.1056-1256)
3. Remove cone (7) and ballast-holder plate (6).
4. Insert the cable inside the bollard through the base (8).
5. Fix the bollard to the ground using plastic expansion caps (9) (not included).
6. Insert wire in the grommet (10) fix it and connect the cables to the terminal block located on the ballast-holder plate (6).
7. Mount the ballast-holder plate using screws (11).
8. Mount cone (7) using the two screws (12).
9. Position the ballast-holder box on the bollard paying attention to the holes alignment.
10. Mount the lamp (not included).
11. Install the antiglare baffle (5) ;(only for art.1056-1256)
12. Tighten the connecting-rod (3), position the diffuser (4) on the ballast-holder box, paying attention to the correct positioning of the gasket.
13. Position the top (1) on the diffuser upper part (4), paying attention to the correct positioning of the gasket.
14. Complete top assembling (1) tightening screws (2) on connecting-rods (3).